



## SUPERB

### General Instructions

Although it is not critical to the success of **SUPERB** Universal Adhesive, it is recommended that the preparation be cleaned with **Clean and Boost**<sup>®</sup> (Gel or Liquid) prior to beginning the bonding protocol. Pumicing or gentle particle abrasion of enamel is also recommended.

### Mode: Self Etch

- Rinse the preparation thoroughly and remove all visible water by drying the surface for approximately **5 seconds** with dried compressed air. Do not desiccate the tooth surface.
- Dispense a drop of **SUPERB** Universal Bond into the cavity of the enclosed mixing well. Using an applicator bristle-type brush, apply 1 coat of **SUPERB** Universal Bond to the entire cavity preparation and the surrounding tooth structure, allow to dwell for 20 seconds. **DO NOT DRY.**
- Using the remaining material in the well and same applicator, apply 2 additional coats of **SUPERB** Universal Bond.
- Dry the surface thoroughly. Do not blast the surface with air or use suction as this could remove material from the surface and lead to debonds or post operative sensitivity.
- Light-activate for ten seconds. **SUPERB** Universal Bond can be activated with any dental activation light.
- Continue restorative procedure with material of choice. Follow manufacturer's instructions for all restorative materials.

NOTE: Deciduous teeth are treated in the same manner as permanent teeth.

NOTE: Uncut enamel should be roughened or etched prior to bonding.

NOTE: **SUPERB** Universal Adhesive is always light-activated before placing veneers and bonded crowns.

## Mode: Selective Etch

- Rinse the preparation thoroughly and remove all visible water by drying the surface for approximately **5 seconds** with dried compressed air. Do not desiccate the tooth surface.
- Apply **Clean & Boost™** Gel to the enamel surfaces to be bonded. Allow material to dwell for 15 seconds, rinse thoroughly and leave moist.
- Dispense a drop of **SUPERB** Universal Bond into the cavity of the enclosed mixing well. Using an applicator bristle-type brush, apply 1 coat of **SUPERB** Universal Bond to the entire cavity preparation and the surrounding tooth structure, allow to dwell for 20 seconds. **DO NOT DRY**
- Using the remaining material in the well and same applicator, apply 2 additional coats of **SUPERB** Universal Bond.
- Dry the surface thoroughly. Do not blast the surface with air or use suction as this could remove material from the surface and lead to debonds or post operative sensitivity.
- Light-activate for ten seconds. **SUPERB** Universal Bond can be activated with any dental activation light.
- Continue restorative procedure with material of choice. Follow manufacturer's instructions for all restorative materials.

NOTE: Deciduous teeth are treated in the same manner as permanent teeth.

NOTE: Uncut enamel should be roughened or etched prior to bonding.

NOTE: **SUPERB** Universal Adhesive is always light-activated before placing veneers and bonded crowns.

## Mode: Total Etch

- Rinse the preparation thoroughly and remove all visible water by drying the surface for approximately **5 seconds** with dried compressed air. Do not desiccate the tooth surface.
- Apply **Clean & Boost** (Gel or Liquid) to the tooth surface to be bonded (both dentin and enamel). Allow material to dwell for 15 seconds, rinse thoroughly and leave moist.
- Dispense a drop of **SUPERB** Universal Bond into the cavity of the enclosed mixing well. Using an applicator bristle-type brush, apply 1 coat of **SUPERB** Universal Bond to the entire cavity preparation and the surrounding tooth structure, allow to dwell for 20 seconds. **DO NOT DRY**
- Using the remaining material in the well and same applicator, apply 2 additional coats of **SUPERB** Universal Bond.
- Dry the surface thoroughly. Do not blast the surface with air or use suction as this could remove material from the surface and lead to debonds or post operative sensitivity.
- Light-activate for ten seconds. **SUPERB** Universal Bond can be activated with any dental activation light.
- Continue restorative procedure with material of choice. Follow manufacturer's instructions for all restorative materials.

NOTE: Deciduous teeth are treated in the same manner as permanent teeth.

NOTE: Uncut enamel should be roughened or etched prior to bonding.

NOTE: **SUPERB** Universal Adhesive is always light-activated before placing veneers and bonded crowns.